4.4.19 Demand Controlled Ventilation

DESCRIPTION

Demand control ventilation (DCV) adjusts outside ventilation air based on the number of occupants and the ventilation demands that those occupants create. DCV is part of a building's ventilation system control strategy. It may include hardware, software, and controls as an integral part of a building's ventilation design. Active control of the ventilation system provides the opportunity to reduce heating and cooling energy use.

The primary component is a control sensor to communicate either directly with the economizer or with a central computer. The component is most typically a carbon dioxide (CO_2) sensor, occupancy sensor, or turnstile counter. This measure is applicable to multiple building types, and savings are classified by the specific building types defined in the Illinois TRM. This measure is modeled to assume night time set backs are in operation and minimum outside air is being used when the building is unoccupied. Systems that have static louvers or that are open at night will likely have greater savings by using the custom program.

This measure was developed to be applicable to the following program types: RF. If applied to other program types, the measure savings should be verified

DEFINITION OF EFFICIENT EQUIPMENT

The efficient equipment condition is defined by new CO_2 sensors installed on return air systems where no other sensors were previously installed. For heating savings, this measure does not apply to any system with terminal reheat (constant volume or variable air volume). For terminal reheat system a custom savings calculation should be used.

DEFINITION OF BASELINE EQUIPMENT

The base case for this measure is a space with no demand control capability. The current code minimum for outside air (OA) is 17 CFM per occupant (ASHRAE 62.1) which is the value assumed in this measure.

DEEMED LIFETIME OF EFFICIENT EQUIPMENT

The deemed measure life is 10 years and based on CO2 sensor estimated life. [383]

DEEMED MEASURE COST

The deemed measure cost is assumed to be the full cost of installation of a DCV retrofit including sensor cost ($500) and installation ($1000 labor) for a total of $1500[384].

LOADSHAPE

Commercial ventilation C23

COINCIDENCE FACTOR

N/A

[383] During the course of conversations with vendors and Building Automation System (BAS) contractors, it was determined that sensors have to be functional for up to 10 years. It is recommended that they are part of a normal preventive maintenance program in which calibration is an important part of extending useful life. Although they are not subject to mechanical failure, they do fall out of tolerance over time.

[384] Discussion with vendors

Algorithm

CALCULATION OF ENERGY SAVINGS

ELECTRIC ENERGY SAVINGS

ΔkWh = Condition Space/1000 * Savings_Factor

Where:

Conditioned Space = actual square footage of conditioned space controlled by sensor

Elec_Savings_Factor = value in table below based on building type and weather zone[385]

Building Type	Elect_Savings_Factor (kWh/1000 sq ft)				
	Zone 1 (Rockford)	Zone 2 (Chicago)	Zone 3 (Springfield)	Zone 4 (Belleville)	Zone 5 (Marion)
Office - Low-rise	454	456	460	456	462
Office - Mid-rise	430	431	432	428	433
Office- High-rise	448	450	452	449	454
Religious Building	493	509	573	584	605
Restaurant	505	515	553	569	581
Retail - Department Store	620	625	630	638	642
Retail - Strip Mall	380	376	356	406	407
Convenience Store	602	603	610	612	614
Elementary School	317	327	352	352	363
High School	305	316	340	340	352
College/ University	392	410	434	449	462
Healthcare Clinic	353	358	379	383	389
Lodging	576	578	586	588	591
Manufacturing	481	482	482	477	482
Special Assembly Auditorium	410	427	479	494	514
De-fault	451	458	475	482	490

[385] The electric energy savings was calculated using TMY3 weather data and methodology consistent with ASHRAE standards. Savings are calculated on an annual basis for each given temperature zone in Illinois. Energy savings for DCV were developed utilizing standards, inputs and approaches as set forth by ASHRAE 62.1and 90.1, respectively. Building input parameters like square footage, equipment efficiencies and occupancy match those used in the EFLH calculations. Reference calculation found in Demand Control Ventilation 12-30-13.xls.

For example: 7,500 SqFt of low-rise office space in Chicago.

ΔkWh = 7,500 SqFt /1000 SqFt *456 kWh

= 3,420 kWh

SUMMER COINCIDENT PEAK DEMAND SAVINGS

NA

NATURAL GAS SAVINGS

Δtherms = Condition Space/1000 * Therm_Savings_Factor

Where:

Conditioned Space = actual square footage of conditioned space controlled by sensor

Therm _Savings_Factor = value in table below based on building type and weather zone[386]

Building Type	Therm_Savings_Factor (Therm/1000 sq ft)				
	Zone 1 (Rockford)	Zone 2 (Chicago)	Zone 3 (Springfield)	Zone 4 (Belleville)	Zone 5 (Marion)
Office - Low-rise	30	26	23	22	19
Office - Mid-rise	20	17	15	15	13
Office- High-rise	27	23	21	20	17
Religious Building	191	169	150	143	128
Restaurant	135	122	106	104	91
Retail - Department Store	47	42	37	36	32
Retail - Strip Mall	31	27	25	24	21
Convenience Store	23	21	18	17	15
Elementary School	83	73	64	60	53
High School	81	71	63	59	52
College/ University	161	141	124	120	101
Healthcare Clinic	57	50	44	42	38
Lodging	26	23	20	20	20
Manufacturing	21	19	16	15	14

[386] The natural gas energy savings was calculated using TMY3 weather data and methodology consistent with ASHRAE standards. Savings are calculated on an annual basis for each given temperature zone in Illinois. Energy savings for DCV were developed utilizing standards, inputs and approaches as set forth by ASHRAE 62.1 and 90.1, respectively. Building input parameters like square footage, equipment efficiencies and occupancy match those used in the EFLH calculations. Reference calculation found in Demand Control Ventilation 12-30-13.xls.

Building Type	Therm_Savings_Factor (Therm/1000 sq ft)				
	Zone 1 (Rockford)	Zone 2 (Chicago)	Zone 3 (Springfield)	Zone 4 (Belleville)	Zone 5 (Marion)
Special Assembly Auditorium	225	198	179	175	154
De-fault	77	68	60	58	51

For example: 7500 SqFt of low-rise office space in Chicago.

ΔTherms = 7,500 SqFt *26 Therm/1000 SqFt

= 195 Therms

WATER IMPACT DESCRIPTIONS AND CALCULATION

N/A

DEEMED O&M COST ADJUSTMENT CALCULATION

N/A

MEASURE CODE: CI-HVC-DCV-V02-140601

4.4.20 High Turndown Burner for Space Heating Boilers

DESCRIPTION

This measure is for a non-residential boilers equipped with linkageless controls providing space heating with burners having a turndown less than 6:1.[387] Turndown is the ratio of the high firing rate to the low firing rate. When boilers are subjected to loads below the low firing rate, the boiler must cycle on/off to meet the load requirements. A higher turndown ratio reduces burner startups, provides better load control, saves wear-and-tear on the burner, and reduces purge-air requirements, all of these benefits result in better overall efficiency.

This measure was developed to be applicable to the following program types: NC, TOS, RF.

If applied to other program types, the measure savings should be verified.

DEFINITION OF EFFICIENT EQUIPMENT

To qualify the boiler linkageless burner must operate with a turndown greater than or equal to 10:1 and be subjected to loads less than or equal to 30%[388] of the full fire input MBH for greater than 60%[389] of the operating hours.

DEFINITION OF BASELINE EQUIPMENT

The baseline boiler utilizes a linkageless burner with a turndown ration of 6:1 or less and is used primarily for space heating. Redundant boilers do not qualify.

DEEMED LIFETIME OF EFFICIENT EQUIPMENT

The expected measure life is assumed to be 21 years.[390]

DEEMED MEASURE COST

The deemed installed measure cost including labor is approximately $2.53/MBtu/hr.[391]

DEEMED O&M COST ADJUSTMENTS

N/A

LOADSHAPE

N/A

COINCIDENCE FACTOR

N/A

---

[387] The standard turndown ratio for boilers is 6:1. Understanding Fuel Savings in the Boiler Room, ASHRAE Journal, David Eoff, December, 2008 p 38

[388] Focus on Energy Evaluation, Business Programs: Deemed Savings Manual V1.0, March 22, 2010. This factor implies that boilers are 30% oversized on average.

[389] FES Analysis of bin hours based upon a 30% oversizing factor.

[390] "Burner," Obtained from a nation-wide survey conducted by ASHRAE TC 1.8 (Akalin 1978). Data changed by TC 1.8 in 1986.

[391] FES review of PY2/PY3 costs for custom People's and North Shore high turndown burner projects. See High Turndown Costs.xlsx for details.

Algorithm

CALCULATION OF SAVINGS

ELECTRIC ENERGY SAVINGS

N/A

SUMMER COINCIDENT PEAK DEMAND SAVINGS

N/A

NATURAL GAS SAVINGS

Δtherms = Ngi * SF * EFLH / 100

Where:

Ngi = Boiler gas input size (kBtu/hr) = custom

SF = Savings Factor = Percentage of energy loss per hour

= (∑ ((EL_base – EL_eff) * H_cycling)) / H)*100

Where:

EL_base = Base Boiler Percentage of energy loss due to cycling at % of Base Boiler Load where BL_base ≤ TDR_base

= 0.003 * $(Cycles_base)^2$ – 0.001 * Cycles_base [392]

Where:

Cycles_base = Number of Cycles/hour of base boiler

= TDR_base / BL

Where:

BL = % of full boiler load at bin hours being evaluated. This is assumed to be a straight line based on 0% load at the building balance point (assumed to be 55F), and full load corrected for the oversizing (OSF) at the lowest temperature bin of -10 to -5F.

OSF = Oversizing Factor = 1.3[393] or custom

TDR_base = Turndown ratio = 0.33[394] or custom

EL_eff = Efficient Boiler Percentage of energy loss due to cycling at % of Efficient Boiler Load

= 0.003 * $(Cycles_eff)^2$ – 0.001 * Cycles_eff

[392] Release 3.0 Operations & Maintenance Best Practices A Guide to Achieving Operational Efficiency, August 2010, Federal Energy Management Program, US Department of Energy. The equation was determined by plotting the values in Table 9.2.1 – Boiler Cycling Energy Loss.

[393] PA Consulting, KEMA, Focus on Energy Evaluation, Business Programs: Deemed Savings Manual V1.0, March 22, 2010, Page 4-12.

[394] Ibid.

Where:

Cycles_eff = Number of Cycles/hour

= TDR_eff / BL

Where:

TDR_eff = Turndown ratio = 0.10[395] or custom

H_cycling = Hours base boiler is cycling at % of base boiler load

= see table below or custom

H = Total Number of Hours in Heating Season

= 4,946 or custom

100 = convert to a percentage

SF = 69.1 / 4946 *100 = 1.4% or custom (see table below for summary of values)

Temperature	H_cycling	BL	EL_base	EL_eff	(EL_base-EL_eff)* Hours
50 to 55	601	6.0%	8.5%	0.7%	47.2
45 to 50	603	12.0%	2.0%	0.0%	12.0
40 to 45	455	18.0%	0.8%	0.0%	3.8
35 to 40	925	24.0%	0.4%	0.0%	4.0
30 to 35	814	30.0%	0.3%	0.0%	2.1
				Total	69.1

EFLH = Equivalent Full Load Hours for heating are provided in section 4.4 HVAC End Use.

100 = convert kBtu to therms

WATER IMPACT DESCRIPTIONS AND CALCULATION

N/A

DEEMED O&M COST ADJUSTMENT CALCULATION

N/A

MEASURE CODE: CI-HVAC-HTBC-V04-140601

[395] 10:1 ratio used to qualify for efficient equipment.

4.4.21 Linkageless Boiler Controls for Space Heating

DESCRIPTION

This measure is for a non-residential boiler providing space heating and currently having single point positioning combustion control. In single-point positioning control, the fuel valve is linked to the combustion air damper via a jackshaft mechanism to maintain correspondence between fuel and combustion air input. Most boilers with single point positioning control do not maintain low excess air levels over their entire firing range. Generally these boilers are calibrated at high fire, but due to the non-linearity required for efficient combustion, excess air levels tend to dramatically increase as the firing rate decreases. Boiler efficiency drops as the excess air levels are increased.

This measure was developed to be applicable to the following program types: TOS, RF.
If applied to other program types, the measure savings should be verified.

DEFINITION OF EFFICIENT EQUIPMENT

To qualify the boiler burner must have a linkageless control system allowing the combustion air damper position to be adjusted and set for optimal efficiency at several firing rates throughout the burner's firing range. This requires the fuel valve and combustion air damper to each be powered by a separate actuator. An alternative to the combustion air damper is a Variable Speed Drive on the combustion air fan.

DEFINITION OF BASELINE EQUIPMENT

The baseline boiler utilizes single point positioning for the burner combustion control.

DEEMED LIFETIME OF EFFICIENT EQUIPMENT

The expected measure life is assumed to be 16 years.[396]

DEEMED MEASURE COST

The deemed measure cost is estimated at $2.50/MBtu/hr burner input.[397]

DEEMED O&M COST ADJUSTMENTS

N/A

LOADSHAPE

N/A

COINCIDENCE FACTOR

N/A

[396] Total number of hours for heating with a base temperature of 55°F for Chicago, IL as noted by National Climate Data Center

Algorithm

CALCULATION OF SAVINGS

ELECTRIC ENERGY SAVINGS

When a Variable Speed Drive is incorporated, electrical savings are calculated according to the Variable Speed Drive measure.

SUMMER COINCIDENT PEAK DEMAND SAVINGS

N/A

NATURAL GAS SAVINGS

$$\Delta therms = Ngi * SF * EFLH / 100$$

Where:

Ngi = Boiler gas input size (kBtu/hr) = custom

SF = Savings factor

Note: Savings factor is the percentage increase in efficiency as a result of the addition of linkageless burner controls. At an average boiler load of 35%, single point controls are assumed to have excess air of 91%, while linkageless controls are assumed to have 34% excess air.[398] The difference between controls types is 57% at this average operating condition. A 15% reduction in excess air is approximately a 1% increase in efficiency.[399] Therefore the nominal combustion efficiency increase is 57 / 15 * 1% = 3.8%.

= 3.8%

EFLH = Equivalent Full Load Hours for heating are provided in section 4.4 HVAC End Use

100 = convert kBtu to therms

WATER IMPACT DESCRIPTIONS AND CALCULATION

N/A

DEEMED O&M COST ADJUSTMENT CALCULATION

N/A

MEASURE CODE: CI-HVC-LBC-V04-140601

[398] Available and Emerging Technologies for Reducing Greenhouse Gas Emissions from Industrial, Commercial, and Institutional Boilers, Prepared by the Sector Policies and Programs Division Office of Air Quality Planning and Standards U.S. Environmental Protection Agency Research Triangle Park, North Carolina 27711, October 2010, Table 1. ICI Boilers – Summary of Greenhouse Gas Emission Reduction Measures, pg. 8

[399] Department of Energy (DOE). January 2012, Steam Tip Sheet #4, Improve Your Boiler's Combustion Efficiency. Advanced Manufacturing Office. Washington, DC: U.S. Department of Energy. This value was determined as an appropriate average over the stack temperatures and excess air levels indicated.

4.4.22 Oxygen Trim Controls for Space Heating Boilers

DESCRIPTION

This measure is for a non-residential boiler providing space heating without oxygen trim combustion controls. Oxygen trim controls limit the amount of excess oxygen provided to the burner for combustion. This oxygen level is dependent upon the amount of air provided. Oxygen trim control converts parallel positioning, linkageless controls, into a closed-loop control configuration with the addition of an exhaust gas analyzer and PID controller. Boilers with oxygen trim controls can maintain a predetermined excess air rate (generally 15% to 30% excess air) over the entire burner firing rate. Boilers without these controls typically have excess air rates around 30% over the entire firing rate. Boiler efficiency drops as the excess air levels are increased.

This measure was developed to be applicable to the following program types: NC, TOS, RF.

If applied to other program types, the measure savings should be verified.

DEFINITION OF EFFICIENT EQUIPMENT

To qualify the boiler burner must have an oxygen control system allowing the combustion air to be adjusted to maintain a predetermined excess oxygen level in the flue exhaust at all firing rates throughout the burner's firing range. This requires an oxygen sensor in the flue exhaust and linkageless fuel valve and combustion air controls.

DEFINITION OF BASELINE EQUIPMENT

The baseline boiler utilizes single point positioning for the burner combustion control.

DEEMED LIFETIME OF EFFICIENT EQUIPMENT

The measure life for the O2 Trim controls is 18 years.[400]

DEEMED MEASURE COST

The deemed measure cost is approximately $23,250.[401]

LOADSHAPE

N/A

COINCIDENCE FACTOR

N/A

[400] State of Wisconsin Public Service Commission of Wisconsin Focus on Energy Evaluation Business Programs: Measure Life Study Final Report: August 25, 2009, Table 1-2. Recommended Measure Life by WISeerts Group Description, pg. 1-4.
[401] CODES AND STANDARDS ENHANCEMENT INITIATIVE (CASE) PROCESS BOILERS, 2013 California Building Energy Efficiency Standards, California Utilities Statewide Codes and Standards Team, October 2011, pg. 22

Algorithm

CALCULATION OF SAVINGS

ELECTRIC ENERGY SAVINGS

N/A

SUMMER COINCIDENT PEAK DEMAND SAVINGS

N/A

NATURAL GAS ENERGY SAVINGS

Δtherms = Ngi * SF * EFLH / 100

Where:

Ngi = Boiler gas input size (kBtu/hr)

= Custom

SF = Savings factor

Note: Savings factor is the percentage reduction in gas consumption as a result of the addition of O2 trim controls. Linkageless controls have an excess air rate of 28% over the entire firing range.[402] O2 trim controls have an excess air rate of 15%.[403] The average difference is 13%. A 15% reduction in excess air is approximately a 1% increase in efficiency.[404] Therefore the nominal combustion efficiency increase is 13 / 15 * 1% = 0.87%.

= 0.87%

EFLH = Default Equivalent Full Load Hours for heating are provided in section 4.4 HVAC End Use. When available, actual hours should be used.

100 = convert kBtu to therms

WATER IMPACT DESCRIPTIONS AND CALCULATION

N/A

DEEMED O&M COST ADJUSTMENT CALCULATION

The deemed annual Operations and Maintenance cost is $800.[405]

MEASURE CODE: CI-HVC-O2TC-V01-140601

[402] Department of Energy (DOE). 2009. Energy Matters newsletter. Fall 2009- Vol. 1, Iss. 1. Washington, DC: U.S. Department of Energy, Office of Energy Efficiency and Renewable Energy, Industrial Technologies Program.
[403] Ibid

[405] Department of Energy (DOE). January 2012, Steam Tip Sheet #4, Improving Your Boiler's Combustion Efficiency. Advanced Manufacturing Office. Washington, DC: U.S. Department of Energy. This value was determined as an appropriate average over the stack temperatures and excess air levels indicated.

4.4.23 Shut Off Damper for Space Heating Boilers or Furnaces

DESCRIPTION

This measure is for non-residential atmospheric boilers or furnaces providing space heating without a shut off damper. When appliances are on standby mode warm room air is drawn through the stack via the draft hood or dilution air inlet at a rate proportional to the stack height, diameter and outdoor temperature. More air is drawn through the vent immediately after the appliance shuts off and the flue is still hot. Installation of a new shut off damper can prevent heat from being drawn up the warm vent and reducing the amount of air that passes through the furnace or boiler heat exchanger. This reduction in air can slightly increase overall operating efficiency by reducing the time needed to achieve steady-state operating conditions.

This measure was developed to be applicable to the following program types: RF.

If applied to other program types, the measure savings should be verified.

DEFINITION OF EFFICIENT EQUIPMENT

To qualify the space heating boiler or furnace must have a new electrically or thermally activated shut off damper installed on either the exhaust flue or combustion air intake. Barometric dampers do not qualify. The damper actuation shall be interlocked with the firing controls.

DEFINITION OF BASELINE EQUIPMENT

The baseline boiler or furnace incorporates no shut off damper on the combustion air intake or flue exhaust.

DEEMED LIFETIME OF EFFICIENT EQUIPMENT

The measure life for the shut off damper is 15 years.[406]

DEEMED MEASURE COST

The deemed measure cost for this approximately $1,500.[407]

LOADSHAPE

N/A

COINCIDENCE FACTOR

N/A

[406] State of Wisconsin Public Service Commission of Wisconsin Focus on Energy Evaluation Business Programs: Measure Life Study Final Report: August 25, 2009, Table 1-2. Recommended Measure Life by WISeerts Group Description, pg. 1-4.
[407] CODES AND STANDARDS ENHANCEMENT INITIATIVE (CASE) PROCESS BOILERS, 2013 California Building Energy Efficiency Standards, California Utilities Statewide Codes and Standards Team, October 2011, pg. 22

Algorithm

CALCULATION OF SAVINGS

ELECTRIC ENERGY SAVINGS

N/A

SUMMER COINCIDENT PEAK DEMAND SAVINGS

N/A

NATURAL GAS ENERGY SAVINGS

Δtherms = Ngi * SF * EFLH / 100

Where:

Ngi = Boiler gas input size (kBtu/hr)

= Custom

SF = Savings factor

= 1%[408]

Note: The savings factor assumes the boiler or furnace is located in an unconditioned space. The savings factor can be higher for those units located within conditioned space.

EFLH = Default Equivalent Full Load Hours for heating are provided in section 4.4 HVAC End Use. When available, actual hours should be used.

100 = convert kBtu to therms

WATER IMPACT DESCRIPTIONS AND CALCULATION

N/A

DEEMED O&M COST ADJUSTMENT CALCULATION

The deemed annual Operations and Maintenance cost is $112.[409]

MEASURE CODE: CI-HVC-SODP-V01-140601

[408] Based on internet review of savings potential;
"Up to 4%": Use of Automatic Vent Dampers for New and Existing Boilers and Furnaces, Energy Innovators Initiative Technical Fact Sheet, Office of Energy Efficiency, Canada, 2002
"Up to 1%": Page 9, The Carbon Trust, "Steam and high temperature hot water boilers" http://www.carbontrust.com/media/13332/ctv052_steam_and_high_temperature_hot_water_boilers.pdf,
"1 - 2%": Page 2, Sustainable Energy Authority of Ireland "Steam Systems Technical Guide", http://www.seai.ie/Your_Business/Technology/Buildings/Steam_Systems_Technical_Guide.pdf.
[409] CODES AND STANDARDS ENHANCEMENT INITIATIVE (CASE) PROCESS BOILERS, 2013 California Building Energy Efficiency Standards, California Utilities Statewide Codes and Standards Team, October 2011, pg. 22

4.4.24 Small Pipe Insulation

DESCRIPTION

This measure provides rebates for adding insulation to bare pipes with inner diameters of ½" and ¾". Insulation must be at least one inch thick. Since new construction projects are required by code to have pipe insulation, this measure is only for retrofits of existing facilities. This covers bare straight pipe as well as all fittings.

Default savings are provided on a per linear foot basis. It is assumed that the majority of pipes less than one inch in commercial facilities are used for domestic hot water. However, this measure can cover hydronic heating systems as well as low and high pressure steam systems.

This measure was developed to be applicable to the following program types: RF.

If applied to other program types, the measure savings should be verified.

DEFINITION OF EFFICIENT EQUIPMENT

The efficient case is a ½"or ¾" diameter pipe with at least one inch of insulation. Insulation must be protected from damage which includes moisture, sunlight, equipment maintenance and wind. Outdoor pipes should have a weather protective jacket. Insulation must be continuous over straight pipe, elbows and tees.

DEFINITION OF BASELINE EQUIPMENT

The base case for savings estimates is a bare hot water or steam pipe with a fluid temperature of 105 degrees Fahrenheit or greater. Current new construction code requires insulation amounts similar to this measure though this base case is commonly found in older existing buildings.

DEEMED LIFETIME OF EFFICIENT EQUIPMENT

The measure life is assumed to be 15 years.[410]

DEEMED MEASURE COST

The incremental measure cost for insulation is the full cost of adding insulation to the pipe. Actual installation costs should be used for the measure cost. For planning purposes, the following costs can be used to estimate the full cost of materials and labor.[411]

Insulation Thickness	¾" pipe	½" pipe
1"	$4.45	$4.15

LOADSHAPE

N/A

[410] Measure Life Report, Residential and Commercial/Industrial Lighting and HVAC Measures, GDS Associates, June 2007. http://neep.org/uploads/EMV%20Forum/EMV%20Studies/measure_life_GDS%5B1%5D.pdf
[411] A market survey was performed to determine these costs.

COINCIDENCE FACTOR

N/A

Algorithm

CALCULATION OF ENERGY SAVINGS

ELECTRIC ENERGY SAVINGS

N/A

SUMMER COINCIDENT PEAK DEMAND SAVINGS

N/A

NATURAL GAS SAVINGS

Δtherms per foot[412] = $[((Q_{base} – Q_{eff}) * EFLH) / (100,000 * \eta Boiler)] * TRF$

= [Provided by tables below] * TRF

Δtherms = $(L_{sp} + L_{oc,i})$ * Δtherms per foot

Where:

EFLH = Equivalent Full Load Hours for Heating

= Actual or defaults by building type provided in Section 4.4, HVAC end use

For year round recirculation or domestic hot water:

= 8,766

For heating season recirculation, hours with the outside air temperature below 55°F:

Zone	Hours
Zone 1 (Rockford)	5,039
Zone 2 (Chicago)	4,963
Zone 3 (Springfield)	4,495
Zone 4 (Belleville/	4,021
Zone 5 (Marion)	4,150

Q_{base} = Heat Loss from Bare Pipe (Btu/hr/ft)

[412]This value comes from the reference table "Savings Summary by Building Type and System Type." The formula and the input tables in this section document assumptions used in calculation spreadsheet "Pipe Insulation Savings 2013-11-12.xlsx"

= See table below

Q_{eff} = Heat Loss from Insulated Pipe (Btu/hr/ft)

= See table below

100,000 = conversion factor (1 therm = 100,000 Btu)

ηBoiler = Efficiency of the boiler being used to generate the hot water or steam in the pipe

= 81.9% for water boilers [413]

= 80.7% for steam boilers, except multifamily low-pressure [414]

= 64.8% for multifamily low-pressure steam boilers [415]

TRF = Thermal Regain Factor for space type, applied only to space heating energy and is applied to values resulting from Δtherms/ft tables below [416]

= See table below for base TRF values by pipe location

May vary seasonally such as: TRF[summer] * summer hours + TRF[winter] * winter hours where TRF values reflecting summer and winter conditions are apportioned by the hours for those conditions. TRF may also be adjusted by building specific balance temperature and operating hours above and below that balance temperature.417

Pipe Location	Assumed Regain	TRF, Thermal Regain Factor
Outdoor	0%	1.0
Indoor, heated space	85%	0.15
Indoor, semi- heated, (unconditioned space, with heat transfer to conditioned space. E.g.: boiler room, ceiling plenum, basement, crawlspace, wall)	30%	0.70
Indoor, unheated, (no heat transfer to conditioned space)	0%	1.0
Location not specified	85%	0.15
Custom	Custom	1 – assumed regain

L_{sp} = Length of straight pipe to be insulated (linear foot)

$L_{oc,i}$ = Total equivalent length of (elbows and tees) of pipe to be insulated. Use table below to

[413] Average efficiencies of units from the California Energy Commission (CEC).
[414] Ibid.
[415] Katrakis, J. and T.S. Zawacki. "Field-Measured Seasonal Efficiency of Intermediate-sized Low-Pressure Steam Boilers". ASHRAE V99, pt. 2, 1993.
[416] Thermal regain for *residential* pipe insulation measures is discussed in Home Energy Services Impact Evaluation, prepared for the Massachusetts Residential Retrofit and Low Income Program Area Evaluation, Cadmus Group, Inc., August 2012 and Andrews, John, Better Duct Systems for Home Heating and Cooling, U.S. Department of Energy, 2001. Recognizing the differences between residential and commercial heating systems, the factors have been adjusted based on professional judgment. This factor would benefit from additional study and evaluation.
[417] Thermal Regain Factor_4-30-14.docx

determine equivalent lengths.

Nominal Pipe Diameter	Equivalent Length (ft)	
	90 Degree Elbow	Straight Tee
1/2"	0.04	0.03
3/4"	0.06	0.05

Q_{base} = Heat Loss from Bare Pipe (Btu/hr/ft). Calculated with the 3E Plus software.

Q_{eff} = Heat Loss from Insulated Pipe (Btu/hr/ft). Calculated with the 3E Plus software.

The table below shows the deemed therm savings by building type and region on a per linear foot basis for both ½" and ¾" copper pipe.

The following table provides deemed values for 1/2" copper pipe, temperatures are assumed by category below, and insulation is assumed to be one inch fiberglass.

Piping Use	Building Type	Annual Therms Saved / Linear Foot				
		Zone 1 (Rockford)	Zone 2 (Chicago)	Zone 3 (Springfield)	Zone 4 (Belleville)	Zone 5 (Marion)
Space Heating Non-recirculating	Assembly	0.117	0.120	0.107	0.071	0.109
	Assisted Living	0.110	0.107	0.094	0.069	0.083
	College	0.100	0.093	0.083	0.046	0.055
	Convenience Store	0.097	0.089	0.079	0.057	0.064
	Elementary School	0.116	0.113	0.100	0.069	0.084
	Garage	0.064	0.063	0.056	0.044	0.049
	Grocery	0.105	0.105	0.092	0.057	0.068
	Healthcare Clinic	0.103	0.106	0.092	0.063	0.066
	High School	0.120	0.121	0.109	0.077	0.091
	Hospital - CAV no econ	0.115	0.119	0.101	0.087	0.099
	Hospital - CAV econ	0.117	0.121	0.103	0.089	0.101
	Hospital - VAV econ	0.048	0.045	0.034	0.020	0.022
	Hospital - FCU	0.087	0.099	0.080	0.094	0.127
	Hotel/Motel	0.115	0.112	0.101	0.069	0.084
	Hotel/Motel - Common	0.104	0.106	0.101	0.082	0.086
	Hotel/Motel - Guest	0.115	0.111	0.099	0.066	0.082
	Manufacturing Facility	0.068	0.066	0.061	0.037	0.041
	MF - High Rise	0.100	0.098	0.090	0.076	0.076

Piping Use	Building Type	Annual Therms Saved / Linear Foot				
		Zone 1 (Rockford)	Zone 2 (Chicago)	Zone 3 (Springfield)	Zone 4 (Belleville)	Zone 5 (Marion)
	MF - High Rise - Common	0.118	0.115	0.103	0.071	0.092
	MF - High Rise - Residential	0.096	0.096	0.087	0.075	0.073
	MF - Mid Rise	0.109	0.110	0.095	0.070	0.079
	Movie Theater	0.119	0.117	0.109	0.083	0.099
	Office - High Rise - CAV no econ	0.132	0.134	0.122	0.082	0.089
	Office - High Rise - CAV econ	0.136	0.139	0.128	0.088	0.097
	Office - High Rise - VAV econ	0.100	0.102	0.084	0.050	0.055
	Office - High Rise - FCU	0.073	0.072	0.062	0.033	0.035
	Office - Low Rise	0.093	0.093	0.074	0.045	0.052
	Office - Mid Rise	0.103	0.104	0.088	0.056	0.062
	Religious Building	0.105	0.098	0.094	0.069	0.079
	Restaurant	0.088	0.088	0.079	0.060	0.071
	Retail - Department Store	0.091	0.083	0.078	0.051	0.058
	Retail - Strip Mall	0.087	0.081	0.071	0.049	0.053
	Warehouse	0.095	0.089	0.091	0.057	0.070
	Unknown	0.101	0.100	0.089	0.064	0.074
Space Heating - recirculation heating season only	All buildings (Hours below 55°F)	0.329	0.324	0.293	0.262	0.271
Space Heating - recirculation year round	All buildings (All hours)	0.572	0.572	0.572	0.572	0.572
DHW	Recirculation loop	0.572	0.572	0.572	0.572	0.572
Process	Custom	Custom				

The following table provides deemed savings values for 3/4" copper pipe with temperatures assumed by category below, insulation is assumed to be one inch fiberglass.

Piping Use	Building Type	Annual Therms Saved / Linear Foot				
		Zone 1 (Rockford)	Zone 2 (Chicago)	Zone 3 (Springfield)	Zone 4 (Belleville)	Zone 5 (Marion)
Space Heating Non-recirculating	Assembly	0.142	0.145	0.129	0.086	0.132
	Assisted Living	0.133	0.130	0.115	0.084	0.101
	College	0.121	0.113	0.101	0.056	0.067
	Convenience Store	0.117	0.108	0.096	0.069	0.077
	Elementary School	0.141	0.137	0.121	0.084	0.102
	Garage	0.078	0.077	0.067	0.054	0.060
	Grocery	0.127	0.127	0.111	0.069	0.083
	Healthcare Clinic	0.125	0.128	0.112	0.076	0.081
	High School	0.146	0.147	0.132	0.094	0.110
	Hospital - CAV no econ	0.140	0.144	0.123	0.105	0.120
	Hospital - CAV econ	0.142	0.147	0.125	0.108	0.123
	Hospital - VAV econ	0.058	0.055	0.041	0.025	0.027
	Hospital - FCU	0.105	0.120	0.098	0.115	0.154
	Hotel/Motel	0.140	0.136	0.122	0.084	0.102
	Hotel/Motel - Common	0.127	0.129	0.123	0.100	0.105
	Hotel/Motel - Guest	0.139	0.135	0.120	0.081	0.099
	Manufacturing Facility	0.083	0.080	0.074	0.045	0.050
	MF - High Rise	0.121	0.119	0.109	0.093	0.093
	MF - High Rise - Common	0.144	0.140	0.125	0.086	0.111
	MF - High Rise - Residential	0.117	0.116	0.105	0.091	0.089
	MF - Mid Rise	0.132	0.134	0.115	0.085	0.096
	Movie Theater	0.144	0.142	0.133	0.101	0.120
	Office - High Rise - CAV no econ	0.160	0.162	0.148	0.099	0.108
	Office - High Rise - CAV econ	0.165	0.169	0.155	0.107	0.118
	Office - High Rise - VAV econ	0.121	0.123	0.102	0.060	0.067
	Office - High Rise - FCU	0.089	0.087	0.075	0.040	0.042
	Office - Low Rise	0.113	0.113	0.090	0.055	0.063
	Office - Mid Rise	0.126	0.126	0.106	0.068	0.075
	Religious Building	0.127	0.119	0.114	0.084	0.095

Piping Use	Building Type	Annual Therms Saved / Linear Foot				
		Zone 1 (Rockford)	Zone 2 (Chicago)	Zone 3 (Springfield)	Zone 4 (Belleville)	Zone 5 (Marion)
	Restaurant	0.107	0.107	0.096	0.073	0.086
	Retail - Department Store	0.110	0.101	0.095	0.062	0.071
	Retail - Strip Mall	0.106	0.098	0.086	0.059	0.064
	Warehouse	0.115	0.108	0.111	0.069	0.085
	Unknown	0.123	0.122	0.108	0.078	0.090
Space Heating - recirculation heating season only	All buildings (Hours below 55°F)	0.399	0.393	0.356	0.319	0.329
Space Heating - recirculation year round	All buildings (All hours)	0.694	0.694	0.694	0.694	0.694
DHW	Recirculation loop	0.694	0.694	0.694	0.694	0.694
Process	Custom	Custom				

WATER IMPACT DESCRIPTIONS AND CALCULATION

N/A

DEEMED O&M COST ADJUSTMENT CALCULATION

N/A

MEASURE Code: CI-HVC-SPIN-V01-150601

4.4.25 Small Commercial Programmable Thermostat Adjustments

DESCRIPTION

This measure involves reprogramming existing commercial programmable thermostats or building automation systems for reduced energy consumption through adjustments of unoccupied heating/cooling setpoints and/or fan control. This measure is limited to packaged HVAC units that are controlled by a commercial thermostat or building automation system. The measure is limited to select building types presented below.

Eligible Small Commercial Building Types

Building Type
Assembly
Convenience Store
Office - Low Rise
Restaurant - Fast Food
Religious Facility
Restaurant - Full Service
Retail - Strip Mall
Retail - Department Store

This measure was developed to be applicable to the following program types: RF, DI.

If applied to other program types, the measure savings should be verified.

DEFINITION OF EFFICIENT EQUIPMENT

The criteria for this measure is established by optimizing heating/cooling temperature setbacks and fan operation with a commercial programmable thermostat or building automation system, which reprogrammed to match actual facility occupancy.

DEFINITION OF BASELINE EQUIPMENT

The baseline for this measure is a commercial programmable thermostat or building automation system that is currently operating packaged HVAC units with heating/cooling temperature setbacks and fan operation that do not align with a facilities actual occupancy.

DEEMED LIFETIME OF EFFICIENT EQUIPMENT

The expected measure life of a programmable thermostat is assumed to be 8 years[418] based upon equipment life only[419]. For the purposes of claiming savings for a adjustment of an existing programmable thermostat, this is

[418] Table 1, HVAC Controls, Measure Life Report, Residential and Commercial/Industrial Lighting and HVAC Measures, GDS Associates, 2007

[419] Future evaluation is strongly encouraged to inform the persistence of savings to further refine measure life assumption.

reduced to a 25% persistence factor to give a final measure life of 2 years. It is recommended that this assumption be evaluated by future energy measurement and verification activities.

DEEMED MEASURE COST

Actual labor costs should be used if the implementation method allows. If unknown the labor cost for this measure is assumed to be $70.34[420] per thermostat, as summarized in the table below.

Measure	Units	Materials	Labor	Total Cost (including O&P)	City Cost Index (Install Only)*	Total	Source
Adjust Temperature Set Points	4	$0.00	$5.95	$6.55	134.5%	$35.24	RS Means 2010 (pg 255, Section 23-09-8100)
Adjust Fan Schedule	2	$0.00	$11.86	$13.05	134.5%	$35.10	RS Means 2010 (pg 255, Section 23-09-8120)
Totals						**$70.34**	

* Chicago, IL - Division 23

LOADSHAPE

N/A

COINCIDENCE FACTOR

N/A

[420] RSMeans, "Instrumentation and Control for HVAC", Mechanical Cost Data , Kingston, MA: Reed Construction Data, 2010, pg. 255 & 632

Algorithm

CALCULATION OF SAVINGS

ELECTRIC ENERGY SAVINGS[421]

ΔkWh = [Baseline Energy Use (kWh/Ton) – Proposed Energy Use (kWh/Ton)] * Cooling Capacity (Tons)

The following equations are used to calculate baseline and proposed electric energy use. The savings is the difference between the proposed and baseline calculated usage. This approach allows the savings estimate to account for the operational attributes of the baseline as well as the proposed case, yielding a better estimate than an approach that assumes a particular baseline or proposed energy use to determine savings.

Electric Energy Use Equations (kWh / ton)

Building Type	Fan Mode During Occupied Period (*Fo*)	Equation
Assembly	Continuous	***CZ***+***Fu****(0.83****Tc***+0.83****Th***+1.67****Ws***-293.018)-0.0922****Tc*******Th***+1.291****Ws***
	Intermittent	***CZ***+***Fu****(1.911-0.12****Tc***)+***Tc****(0.00311****Ws***-0.229)+0.11****Ws***
Convenience Store	Continuous	***CZ***+***Fu****(-28.629****Tc***-11.69****Th***+19.118****Ws***-2935.12)+0.909****Ws***
	Intermittent	***CZ***+***Tc****(0.0863****Ws***-12.688)+***Th****(0.043****Ws***-6.38)+1.669****Ws***
Office – Low Rise	Continuous	***CZ***+***Fu****(7.082****Tc***-41.199****Th***+18.734****Ws***-3288.55)+***Tc****(0.205****Ws***-34.929)
	Intermittent	***CZ***+***Tc****(0.0806****Ws***-8.984)+***Th****(0.0864****Ws***-9.558)+1.178****Ws***
Religious	Continuous	***CZ***+***Fu****(-1.579****Tc***-18.14****Th***+15.01****Ws***-2417.74)+***Tc****(0.177****Ws***-26.412)
	Intermittent	***CZ***+***Fu****(0.266****Tc***-2.067)+***Tc****(0.0295****Ws***-4.502)+***Th****(0.0517****Ws***-8.251)+0.735****Ws***
Restaurant – Fast Food	Continuous	***CZ***+***Fu****(0.678****Tc***+0.257****Th***+2.88****Ws***-494.006)+***Tc****(0.0231****Ws***-4.074)+***Th****(0.00936****Ws***-1.655)+0.918****Ws***
	Intermittent	***CZ***+***Fu****(0.377****Tc***+0.124****Th***+0.13****Ws***-24.893)+***Tc****(-0.0143****Th***+0.0166****Ws***-2.691)+0.898****Ws***
Restaurant – Sit Down	Continuous	***CZ***+***Fu****(-8.41****Th***+11.766****Ws***-1910.81)+***Tc****(0.282****Ws***-43.851)
	Intermittent	***CZ***+0.123****Fu*******Tc***+***Tc****(0.0561****Ws***-8.237)+***Th****(0.0219****Ws***-3.284)+1.038****Ws***
Retail – Large	Continuous	***CZ***+***Fu****(-1.475****Th***+0.755****Ws***-114.373)+***Th****(0.151****Ws***-24.016)+1.612****Ws***
	Intermittent	***CZ***+***Tc****(0.0173****Ws***-1.912)+***Th****(0.0249****Ws***-3.29)+0.511****Ws***
Retail – Strip Mall	Continuous	***CZ***+***Fu****(1.077****Tc***-10.697****Th***+6.91****Ws***-1117.18)+***Tc****(0.0583****Ws***-7.54)+1.231****Ws***
	Intermittent	***CZ***+0.0894****Fu*******Tc***+***Th****(-0.0142****Tc***+0.04****Ws***-5.278)+0.884****Ws***

Where:

CZ = Climate Zone Coefficient

= Depends on Building Type and Fan Mode During Occupied Period (see table below)

[421] Savings equations and factors determined by regression of results of a series of eQuest simulations. See Programmable T-Stat Work Paper_PECI_FinalDraft_140730_Redline.docx for details.

Tc = Degrees of Cooling Setback °F

= Must be between 0-15°F

Th = Degrees of Heating Setback °F

=Must be between 0-15°F

Fo = Fan Mode During Occupied Period (Note: Commercial mechanical code requires continuous fan operation during occupied periods to meet ventilation requirements.)

= Continuous for occupied fan that runs continuously (e.g. Fan Mode Set to 'On')

= Intermittent for occupied fan that runs intermittently (e.g. Fan Mode Set to 'Auto')

Fu = Fan Mode during Unoccupied Period

= 0 for unoccupied fan that runs continuously (e.g. Fan Mode Set to 'On')

= 1 for unoccupied fan that runs intermittently (e.g. Fan Mode Set to 'Auto')

Ws = Weekly Hours thermostat is in Occupied mode,

= Minimum values depend on Building Type (see table below), maximum value of 168 (24/7) ex: Weekly occupancy schedule of Mon-Sat 8AM-5PM, Sun 9AM-2PM, Ws = 59

Electric Energy Use Climate Zone Coefficients and Minimum Weekly Hours Occupied

Building Type	Fan Mode During Occupied Period (*Fo*)	Climate Zone Coefficient (*CZ*)					Minimum *Ws*
		1	2	3	4	5	
Assembly	Continuous	911.366	928.924	1152.83	1208.999	1210.173	98
	Intermittent	735.752	762.831	966.562	998.927	1028.906	
Convenienc e Store	Continuous	4817.094	4832.784	5139.133	5182.161	5208.608	108
	Intermittent	1478.133	1514.568	1784.384	1843.463	1930.47	
Office - Low Rise	Continuous	5047.662	5039.592	5187.924	5217.672	5177.449	55
	Intermittent	825.072	808.965	946.571	979.421	945.418	
Religious Facility	Continuous	4197.117	4172.858	4380.025	4370.008	4356.054	133
	Intermittent	632.404	603.395	678.294	664.717	616.853	
Restaurant – Fast Food	Continuous	1342.988	1378.661	1664.018	1714.201	1727.841	108
	Intermittent	993.764	1039.643	1307.8	1340.544	1389.791	
Restaurant – Full Service	Continuous	4070.35	4094.742	4428.966	4501.829	4522.522	117
	Intermittent	1472.014	1516.05	1856.108	1938.441	2056.45	
Retail – Department Store	Continuous	1510.201	1496.47	1706.105	1716.128	1688.464	93
	Intermittent	701.27	702.129	847.735	875.12	881.677	
Retail – Strip Mall	Continuous	1926.294	1930.137	2156.856	2174.435	2165.03	93
	Intermittent	656.479	673.257	835.906	850.322	869.921	

EXAMPLE

A low rise office building in Rockford (Climate Zone 1) is occupied Mon-Fri 7AM-6PM and is heated and cooled with a packaged Gas (150 kBtu output) / DX (10 Ton) RTU which is controlled by a programmable thermostat. When the technician reviews the thermostat schedule they find the unoccupied schedule is programmed incorrectly. During the unoccupied periods the fan is programmed correctly, and runs in intermittent "auto" mode, although the heating and cooling temperature setpoints are not setback.

The technician adjusts the unoccupied schedule to include a 10°F cooling and heating temperature setback during the unoccupied periods.

ΔkWh = [Baseline Energy Use (kWh/Ton) – Proposed Energy Use (kWh/Ton)] * Cooling Capacity (Tons)

Baseline Energy Use (kWh/Ton) = Equation for Office Low Rise, *Fo*=Continuous

= ***CZ***+***Fu****(7.082****Tc***-41.199****Th***+18.734****Ws***-3288.55)+***Tc****(0.205****Ws***-34.929)

= ***5047.662***+1*(7.082****0***-41.199****0***+18.734****55***-3288.55)+***0****(0.205****55***-34.929)

= 2,789.482 kWh/Ton

Proposed Energy Use (kWh/Ton) = Equation for Office Low Rise, *Fo*=Continuous

= ***CZ***+***Fu****(7.082****Tc***-41.199****Th***+18.734****Ws***-3288.55)+***Tc****(0.205****Ws***-34.929)

= ***5047.662***+***1****(7.082****10***-41.199***10**+18.734***55**-3288.55)+***10*(***0.205****55***-34.929)

= 2,211.722 kWh/Ton

ΔkWh = [2,789.482 (kWh/Ton) – 2,211.722 (kWh/Ton)] * 10 Tons

= 577.71 kWh/Ton * 10 Tons

= 5777.1 kWh

SUMMER COINCIDENT PEAK DEMAND SAVINGS

N/A

NATURAL GAS ENERGY SAVINGS

ΔTherms = [Baseline Energy Use (Therms/kBtuh) – Proposed Energy Use(Therms/kBtuh)] * Output Heating Capacity (kBtuh)

The following equations are used to calculate baseline and proposed natural gas energy use. The savings is the difference between the proposed and baseline calculated usage. This approach allows the savings estimate to account for the operational attributes of the baseline as well as the proposed case, yielding a better estimate than an approach that assumes a particular baseline or proposed energy use to determine savings.

Natural Gas Energy Use Equations (therms / kbtu)

Building Type	Fan Mode During Occupied Period (*Fo*)	Equation
Assembly	Continuous	CZ+Fu*(0.232*Th+0.0984*Ws-18.79)+Th*(0.00271*Ws-0.535)+0.0142*Ws
	Intermittent	***CZ***+***Fu****(0.00405****Th***+0.000519****Ws***-0.11)+***Th****(0.0000689****Ws***-0.0118)+0.0022****Ws***
Convenience Store	Continuous	***CZ***+***Fu****(0.00545****Th***-0.00251****Ws***+0.416)+***Th****(0.000123****Ws***-0.0204)+0.00183****Ws***
	Intermittent	***CZ***+***Fu****(0.00231****Th***-0.0349)+***Th****(0.000309****Ws***-0.0494)+0.00266****Ws***
Office – Low Rise	Continuous	***CZ***+***Fu****(0.0205****Th***+0.364)+***Th****(0.00046****Ws***-0.0554)+0.00169****Ws***
	Intermittent	***CZ***+***Fu****(0.00745****Th***-0.142)+***Th****(0.00077****Ws***-0.111)+0.00199****Ws***
Religious	Continuous	***CZ***+0.00791****Fu*******Th***+***Th****(0.00096****Ws***-0.167)+0.00184****Ws***
	Intermittent	***CZ***+***Fu****(0.00143****Th***-0.0309)+***Th****(0.0008****Ws***-0.134)+0.00219****Ws***
Restaurant – Fast Food	Continuous	***CZ***+***Fu****(0.0431****Th***+0.0424****Ws***-7.517)+***Th****(0.00113****Ws***-0.213)+0.0119****Ws***
	Intermittent	***CZ***+***Fu****(0.0125****Th***+0.0036****Ws***-0.71)+***Th****(0.000329****Ws***-0.0615)+0.00738****Ws***
Restaurant –Sit Down	Continuous	***CZ***+***Fu****(0.00445****Ws***-0.535)+***Th****(0.000679****Ws***-0.1)+0.00218****Ws***
	Intermittent	***CZ***+***Fu****(0.00144****Th***+0.000262****Ws***-0.0553)+***Th****(0.00018****Ws***-0.0299)+0.00166****Ws***
Retail – Large	Continuous	***CZ***+0.00203****Fu*******Th***+***Th****(0.000591****Ws***-0.0812)+0.00194****Ws***
	Intermittent	***CZ***+***Th****(0.000406****Ws***-0.0611)+0.00228****Ws***
Retail – Strip Mall	Continuous	***CZ***+***Fu****(0.00998****Th***+0.00207****Ws***-0.206)+***Th****(0.000665****Ws***-0.101)+0.00292****Ws***
	Intermittent	***CZ***+***Fu****(0.00383****Th***-0.0656)+***Th****(0.000575****Ws***-0.0912)+0.00249****Ws***

Where:

CZ = Climate Zone Coefficient

= Depends on Building Type and Fan Mode During Occupied Period (see table below)

Th = Degrees of Heating Setback °F

= Must be between 0-15°F

Fo = Fan Mode During Occupied Period (Note: Commercial mechanical code requires continuous fan operation during occupied periods to meet ventilation requirements.)

= Continuous for occupied fan that runs continuously (e.g. Fan Mode Set to 'On')

= Intermittent for occupied fan that runs intermittently (e.g. Fan Mode Set to 'Auto')

Fu = Fan Mode during Unoccupied Period

= 0 for unoccupied fan that runs continuously (e.g. Fan Mode Set to 'On')

= 1 for unoccupied fan that runs intermittently (e.g. Fan Mode Set to 'Auto')

Ws = Weekly Hours thermostat is in Occupied mode,

= Minimum values depends on Building Type (see table below), maximum value of 168 (24/7) ex: Weekly occupancy schedule of Mon-Sat 8AM-5PM, Sun 9AM-2PM, Ws = 59.

Natural Gas Energy Use Climate Zone Coefficients and Minimum Weekly Hours Occupied

Building Type	Fan Mode During Occupied Period (*Fo*)	Climate Zone Coefficient (*CZ*)					Minimum *Ws*
		1	2	3	4	5	
Assembly	Continuous	19.872	17.83	15.828	15.282	13.482	98
	Intermittent	0.237	0.0989	0.0267	0.0131	0.0871	
Convenience Store	Continuous	1.493	1.081	0.782	0.544	0.114	108
	Intermittent	1.128	0.854	0.619	0.437	0.0854	
Office - Low Rise	Continuous	1.718	1.317	0.971	0.739	0.319	55
	Intermittent	3.447	3.022	2.503	2.251	1.646	
Religious Facility	Continuous	6.294	5.55	4.678	4.202	3.122	133
	Intermittent	5.914	5.368	4.557	4.137	3.246	
Restaurant – Fast Food	Continuous	8.383	7.211	6.034	5.767	4.71	108
	Intermittent	1.227	0.636	0.302	0.102	-0.262	
Restaurant – Full Service	Continuous	5.247	4.484	3.753	3.465	2.627	117
	Intermittent	0.951	0.704	0.51	0.381	0.0746	
Retail – Department Store	Continuous	4.385	3.854	3.192	2.784	1.858	93
	Intermittent	3.061	2.672	2.182	1.829	1.008	
Retail – Strip Mall	Continuous	3.917	3.394	2.728	2.394	1.617	93
	Intermittent	2.659	2.292	1.811	1.543	0.909	

EXAMPLE

A low rise office building in Rockford (Climate Zone 1) is occupied Mon-Fri 7AM-6PM and is heated and cooled with a packaged Gas (150 kBtu output) / DX (10 Ton) RTU which is controlled by a programmable thermostat. When the technician reviews the thermostat schedule they find the unoccupied schedule is programmed incorrectly. During the unoccupied periods the fan is programmed correctly, and runs in intermittent "auto" mode, although the heating and cooling temperature setpoints are not setback.

The technician adjusts the unoccupied schedule to include a 10°F cooling and heating temperature setback during the unoccupied periods.

ΔTherms = [Baseline Energy Use (Therms/kBtuh) – Proposed Energy Use(Therms/kBtuh)] * Output Heating Capacity (kBtuh)

Baseline Energy Use (Therms/kBtuh) = Equation for Office Low Rise, *Fo*=Continuous

= ***CZ***+***Fu****(0.0205****Th***+0.364)+***Th****(0.00046****Ws***-0.0554)+0.00169****Ws***

= ***1.718***+***1****(0.0205****0***+0.364)+***0****(0.00046****55***-0.0554)+0.00169****55***

= 2.17495 Therms/kBtuh output

Proposed Energy Use (Therms/kBtuh) = Equation for Office Low Rise, *Fo*=Continuous

= ***CZ***+***Fu****(0.0205****Th***+0.364)+***Th****(0.00046****Ws***-0.0554)+0.00169****Ws***

= ***1.718***+***1****(0.0205****10***+0.364)+***10****(0.00046****55***-0.0554)+0.00169****55***

= 2.07895 Therms/kBtuh output

ΔTherms = [2.17495 (Therms/kBtuh output) – 2.07895 (Therms/kBtuh output)] * 150kBtuh output

= 0.096 (Therms/kBtuh output) * 150kBtuh output

= 14.4 Therms

WATER IMPACT DESCRIPTIONS AND CALCULATION

N/A

DEEMED O&M COST ADJUSTMENT CALCULATION

N/A

MEASURE CODE: CI-HVC- PRGA -V01-150601

4.4.26 Variable Speed Drives for HVAC Supply and Return Fans

DESCRIPTION

This measure is applied to variable speed drives (VSD) which are installed on HVAC supply fans and return fans. There is a separate measure for HVAC pumps and cooling tower fans. All other VSD applications require custom analysis by the program administrator. The VSD will modulate the speed of the motor when it does not need to run at full load. Since the power of the motor is proportional to the cube of the speed for these types of applications, significant energy savings will result.

This measure was developed to be applicable to the following program types: TOS, RF. If applied to other program types, the measure savings should be verified.

DEFINITION OF EFFICIENT EQUIPMENT

The VSD is applied to a motor which does not have a VSD. The application must have a variable load and installation is to include the necessary controls. Savings are based on application of VSDs to a range of baseline load conditions including no control, inlet guide vanes, outlet guide vanes and throttling valves.

DEFINITION OF BASELINE EQUIPMENT

The time of sale baseline is a new motor installed without a VSD or other methods of control. Retrofit baseline is an existing motor operating as is. Retrofit baselines may or may not include guide vanes, throttling valves or other methods of control. This information shall be collected from the customer.

Installations of new equipment with VSDs which are required by IECC 2012 as adopted by the State of Illinois are not eligible for incentives.

DEEMED LIFETIME OF EFFICIENT EQUIPMENT

The expected measure life for HVAC application is 15 years;[422] measure life for process is 10 years.[423]

DEEMED MEASURE COST

Customer provided costs will be used when available. Default measure costs[424] are noted below for up to 20 hp motors. Custom costs must be gathered from the customer for motor sizes not listed below.

HP	Cost
1 -5 HP	$ 1,330
7.5 HP	$ 1,622
10 HP	$ 1,898
15 HP	$ 2,518
20 HP	$ 3,059

LOADSHAPE

Loadshape C39 - VFD - Supply fans <10 HP

Loadshape C40 - VFD - Return fans <10 HP

[422] Efficiency Vermont TRM 10/26/11 for HVAC VSD motors
[423] DEER 2008
[424] Ohio TRM 8/6/2010 varies by motor/fan size based on equipment costs from Granger 2008 Catalog pp 286-289, average across available voltages and models. Labor costs from RS Means Data 2008 Ohio average cost adjustment applied.

Loadshape C41 - VFD - Exhaust fans <10 HP

COINCIDENCE FACTOR

The demand savings factor (DSF) is already based upon coincident savings, and thus there is no additional coincidence factor for this characterization.

Algorithm

CALCULATION OF SAVINGS

ELECTRIC ENERGY SAVINGS[425]

kWh_{Base} = $$\left(0.746 \times HP \times \frac{LF}{\eta_{motor}}\right) \times RHRS_{Base} \times \sum_{0\%}^{100\%} (\%FF \times PLR_{Base})$$

$kWh_{Retrofit}$ = $$\left(0.746 \times HP \times \frac{LF}{\eta_{motor}}\right) \times RHRS_{base} \times \sum_{0\%}^{100\%} (\%FF \times PLR_{Retrofit})$$

ΔkWh_{fan} = $$\mathrm{kWh_{Base}} - \mathrm{kWh_{Retrofit}}$$

ΔkWh_{total} = $$\Delta\mathrm{kWh_{fan}} \times (1 + \mathrm{IE_{energy}})$$

Where:

kWh_{Base} = Baseline annual energy consumption (kWh/yr)

$kWh_{Retrofit}$ = Retrofit annual energy consumption (kWh/yr)

ΔkWh_{fan} = Fan-only annual energy savings

ΔkWh_{total} = Total project annual energy savings

0.746 = Conversion factor for HP to kWh

HP = Nominal horsepower of controlled motor

LF = Load Factor; Motor Load at Fan Design CFM (Default = 65%)[426]

η_{motor} = Installed nominal/nameplate motor efficiency

[425] Methodology developed and tested in Del Balso, Ryan Joseph. "Investigation into the Reliability of Energy Efficiency/Demand Side Management Savings Estimates for Variable Frequency Drives in Commercial Applications". A project report submitted to the Faculty of the Graduate School of the University of Colorado, 2013.

[426] Lawrence Berkeley National Laboratory, and Resource Dynamics Corporation. (2008). "Improving Motor and Drive System Performance; A Sourcebook for Industry". U.S. Department of Energy, Office of Energy Efficiency and Renewable Energy. Golden, CO: National Renewable Energy Laboratory.

Default motor is a NEMA Premium Efficiency, ODP, 4-pole/1800 RPM fan motor

NEMA Premium Efficiency Motors Default Efficiencies[427]

Size HP	Open Drip Proof (ODP)			Totally Enclosed Fan-Cooled (TEFC)		
	# of Poles			# of Poles		
	6	4	2	6	4	2
	Speed (RPM)			Speed (RPM)		
	1200	1800 Default	3600	1200	1800	3600
1	0.825	0.855	0.770	0.825	0.855	0.770
1.5	0.865	0.865	0.840	0.875	0.865	0.840
2	0.875	0.865	0.855	0.885	0.865	0.855
3	0.885	0.895	0.855	0.895	0.895	0.865
5	0.895	0.895	0.865	0.895	0.895	0.885
7.5	0.902	0.910	0.885	0.910	0.917	0.895
10	0.917	0.917	0.895	0.910	0.917	0.902
15	0.917	0.930	0.902	0.917	0.924	0.910
20	0.924	0.930	0.910	0.917	0.930	0.910
25	0.930	0.936	0.917	0.930	0.936	0.917
30	0.936	0.941	0.917	0.930	0.936	0.917
40	0.941	0.941	0.924	0.941	0.941	0.924
50	0.941	0.945	0.930	0.941	0.945	0.930
60	0.945	0.950	0.936	0.945	0.950	0.936
75	0.945	0.950	0.936	0.945	0.954	0.936
100	0.950	0.954	0.936	0.950	0.954	0.941
125	0.950	0.954	0.941	0.950	0.954	0.950
150	0.954	0.958	0.941	0.958	0.958	0.950
200	0.954	0.958	0.950	0.958	0.962	0.954
250	0.954	0.958	0.950	0.958	0.962	0.958
300	0.954	0.958	0.954	0.958	0.962	0.958
350	0.954	0.958	0.954	0.958	0.962	0.958

[427] Douglass, J. (2005). Induction Motor Efficiency Standards. Washington State University and the Northwest Energy Efficiency Alliance, Extension Energy Program, Olympia, WA. Retrieved October 17, 2013, from http://www1.eere.energy.gov/manufacturing/tech_assistance/pdfs/motor_efficiency_standards.pdf

Size HP	Open Drip Proof (ODP)			Totally Enclosed Fan-Cooled (TEFC)		
	# of Poles			# of Poles		
	6	4	2	6	4	2
	Speed (RPM)			Speed (RPM)		
	1200	1800 Default	3600	1200	1800	3600
400	0.958	0.958	0.958	0.958	0.962	0.958
450	0.962	0.962	0.958	0.958	0.962	0.958
500	0.962	0.962	0.958	0.958	0.962	0.958

$RHRS_{Base}$ = Annual operating hours for fan motor based on building type

Default hours are provided for HVAC applications which vary by HVAC application and building type[428]. When available, actual hours should be used.

Building Type	Pumps and fans
College/University	4216
Grocery	5840
Heavy Industry	3585
Hotel/Motel	6872
Light Industry	2465
Medical	6871
Office	2301
Restaurant	4654
Retail/Service	3438
School(K-12)	2203
Warehouse	3222
Average = Miscellaneous	4103

$\%FF$ = Percentage of run-time spent within a given flow fraction range

Default Fan Duty Cycle Based on 2012 ASHRAE Handbook; HVAC Systems and Equipment, page 45.11, Figure 12.

[428] ComEd Trm June 1, 2010 page 139. The Office hours is based upon occupancy from the eQuest model developed for EFLH, since it was agreed the ComEd value was too low.

Flow Fraction (% of design cfm)	Percent of Time at Flow Fraction
0% to 10%	0.0%
10% to 20%	1.0%
20% to 30%	5.5%
30% to 40%	15.5%
40% to 50%	22.0%
50% to 60%	25.0%
60% to 70%	19.0%
70% to 80%	8.5%
80% to 90%	3.0%
90% to 100%	0.5%

PLR_{Base} = Part load ratio for a given flow fraction range based on the baseline flow control type

$PLR_{Retrofit}$ = Part load ratio for a given flow fraction range based on the retrofit flow control type

Control Type	Flow Fraction									
	10%	20%	30%	40%	50%	60%	70%	80%	90%	100%
No Control or Bypass Damper	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00
Discharge Dampers	0.46	0.55	0.63	0.70	0.77	0.83	0.88	0.93	0.97	1.00
Outlet Damper, BI & Airfoil Fans	0.53	0.53	0.57	0.64	0.72	0.80	0.89	0.96	1.02	1.05
Inlet Damper Box	0.56	0.60	0.62	0.64	0.66	0.69	0.74	0.81	0.92	1.07
Inlet Guide Vane, BI & Airfoil Fans	0.53	0.56	0.57	0.59	0.60	0.62	0.67	0.74	0.85	1.00
Inlet Vane Dampers	0.38	0.40	0.42	0.44	0.48	0.53	0.60	0.70	0.83	0.99
Outlet Damper, FC Fans	0.22	0.26	0.30	0.37	0.45	0.54	0.65	0.77	0.91	1.06
Eddy Current Drives	0.17	0.20	0.25	0.32	0.41	0.51	0.63	0.76	0.90	1.04
Inlet Guide Vane, FC Fans	0.21	0.22	0.23	0.26	0.31	0.39	0.49	0.63	0.81	1.04
VFD with duct static pressure controls	0.09	0.10	0.11	0.15	0.20	0.29	0.41	0.57	0.76	1.01
VFD with low/no duct static pressure	0.05	0.06	0.09	0.12	0.18	0.27	0.39	0.55	0.75	1.00

Provided below is the resultant values based upon the defaults provided above:

Control Type	$\sum_{0\%}^{100\%}(\%\boldsymbol{FF} \times \boldsymbol{PLR}_{Base})$
No Control or Bypass Damper	1.00
Discharge Dampers	0.80
Outlet Damper, BI & Airfoil Fans	0.78
Inlet Damper Box	0.69
Inlet Guide Vane, BI & Airfoil Fans	0.63
Inlet Vane Dampers	0.53
Outlet Damper, FC Fans	0.53
Eddy Current Drives	0.49
Inlet Guide Vane, FC Fans	0.39
VFD with duct static pressure controls	0.30
VFD with low/no duct static pressure	0.27

IE_{energy} = HVAC interactive effects factor for energy (default = 15.7%)

SUMMER COINCIDENT PEAK DEMAND SAVINGS

kW_{Base} = $$\left(0.746 \times HP \times \frac{LF}{\eta_{motor}}\right) \times PLR_{Base,FFpeak}$$

$kW_{Retrofit}$ = $$\left(0.746 \times HP \times \frac{LF}{\eta_{motor}}\right) \times PLR_{Retrofit,FFpeak}$$

ΔkW_{fan} = $$\mathrm{kW_{Base}} - \mathrm{kW_{Retrofit}}$$

ΔkW_{total} = $$\Delta\mathrm{kW_{fan}} \times (1 + \mathrm{IE_{demand}})$$

Where:

kW_{Base} = Baseline summer coincident peak demand (kW)

$kW_{Retrofit}$ = Retrofit summer coincident peak demand (kW)

ΔkW_{fan} = Fan-only summer coincident peak demand impact

ΔkW_{total} = Total project summer coincident peak demand impact

$PLR_{Base,FFpeak}$ = The part load ratio for the average flow fraction between the peak daytime hours during the weekday peak time period based on the baseline flow control type (default average flow fraction during peak period = 90%)

$PLR_{Retrofit,FFpeak}$ = The part load ratio for the average flow fraction between the peak daytime hours during the weekday peak time period based on the retrofit flow control type (default average flow fraction during peak period = 90%)

IE_{demand} = HVAC interactive effects factor for summer coincident peak demand (default = 15.7%)

FOSSIL FUEL IMPACT DESCRIPTIONS AND CALCULATION

There are no expected fossil fuel impacts for this measure.

WATER IMPACT DESCRIPTIONS AND CALCULATION

N/A

DEEMED O&M COST ADJUSTMENT CALCULATION

N/A

MEASURE CODE: CI-HVC-VSDF-V01-150601

4.4.27 Energy Recovery Ventilator

DESCRIPTION

This measure includes the addition of energy recovery equipment on existing or new unitary equipment, where energy recovery is not required by the IECC 2012. This measure analyzes the heating savings potential from recovering energy from exhaust or relief building air. This measure assumes during unoccupied hours of the building no exhaust or relief air is available for energy recovery.

This measure was developed to be applicable to the following program types: TOS, NC, RF.

If applied to other program types, the measure savings should be verified.

DEFINITION OF EFFICIENT EQUIPMENT

Efficient equipment is unitary equipment that incorporates energy recovery not required by the IECC 2012.

DEFINITION OF BASELINE EQUIPMENT

The baseline is unitary equipment not require by IECC 2012 to incorporate energy recovery.

DEEMED LIFETIME OF EFFICIENT EQUIPMENT

The measure life for the domestic energy recovery equipment is 15 years.[429]

DEEMED MEASURE COST

The incremental cost for this measure assumes cost of cabinet and controls incorporated into packaged and built up air handler units. Additionally it assumes 1 to 1 ratio of fresh and exhausted air.

Energy Recovery Equipment Type	Incremental Cost $/CFM[430]
Fixed Plate	$6
Rotary Wheel	$6
Heat Pipe	$6

DEEMED O&M COST ADJUSTMENTS

There are no expected O&M savings associated with this measure.

LOADSHAPE

N/A

COINCIDENCE FACTOR

N/A

[429] Assumed service life limited by controls -" Demand Control Ventilation Using CO2 Sensors", pg. 19, by US Department of Energy Efficiency and Renewable Energy

[430] "Map to HVAC Solutions", by Michigan Air, Issue 3, 2006

Algorithm

CALCULATION OF ENERGY SAVINGS

ELECTRIC ENERGY SAVINGS

SUMMER COINCIDENT PEAK DEMAND SAVINGS

There are no anticipated electrical savings from this measure as it is assumed that the additional fan energy due to the increased static pressure drop offsets cooling energy savings. Where this is not expected to be the case, a custom calculation should be used to determine the savings.

NATURAL GAS SAVINGS

Gas savings algorithm is derived from the following:

ΔTherms = (Design Heating Load * TE_ERV * EFLH * OccHours/24) / (100,000 * µHeat)

Where:

Design Heating Load = (1.08 * CFM * ΔT)

1.08 = A constant for sensible heat equations (BTU/h/CFM.°F)

CFM = Cubic Feet per Minute of Energy Recovery Ventilator

ΔT = T_RA – T_DD

T_RA = Temperature of the Return Air = 70°F or custom

T_DD = Temperature on design day of outside air[431]

= (see Table below) or custom

Zone	Weather Station	T_DD, Temperature, °F
1	Greater Rockford	-5.8
2	Chicago/O'Hare ARPT.	-1.5
3	Springfield/Capital	0.4
4	Scott AFB MidAmerica	9.0
5	Cape Girardeau Regional	9.7
Average	-	2.4

TE_ERV = Thermal Effectiveness of Energy Recovery Equipment[432]

[431] Weather Station Data, 99.6% Heating DB - 2013 Fundamentals, ASHRAE Handbook
[432] Energy Recovery Fact Sheet - Center Point Energy, MN

= (see Table below) or custom

Heat Recovery Equipment Type	TE_ERV (%)
Fixed Plate	0.65
Rotary Equipment	0.68
Heat Pipe	0.55

EFLH = Equivalent Full Load Hours for heating are provided in section 4.4 HVAC End Use

OccHour = Average Hours per day facility is occupied

= (see Table 4.4.1 EQuest Modeling Inputs by Building Type) or custom

µHeat = Efficiency of heating system

= Actual

WATER IMPACT DESCRIPTIONS AND CALCULATION

N/A

DEEMED O&M COST ADJUSTMENT CALCULATION

N/A

MEASURE CODE: CI-HVC-ERVE-V01-150601

4.4.28 Stack Economizer for Boilers Serving HVAC Loads

MEASURE DESCRIPTION

Stack economizers are designed to recover heat from hot boiler flue gasses. Recovered heat is used to preheat boiler feed water. This measure describes the retrofit of HVAC boilers with stack economizers. HVAC boilers are defined as those used for space heating applications. There is another, similar measure for boilers that serve process loads.

This measure was developed to be applicable to the following program types: NC, TOS, RF.

If applied to other program types, the measure savings should be verified.

DEFINITION OF EFFICIENT EQUIPMENT

To qualify the economizer must be installed on a boiler exhaust stack. Heat captured by the economizer is to be used to pre-heat boiler feed water.

DEFINITION OF BASELINE EQUIPMENT

The baseline boiler does not have an economizer installed.

DEEMED LIFETIME OF EFFICIENT EQUIPMENT

The measure life for the boiler stack economizer is 15 years.[433]

DEEMED MEASURE COST

The incremental and full measure cost for this measure is custom.

DEEMED O&M COST ADJUSTMENTS

The O&M cost for this measure is custom.

LOADSHAPE

N/A

COINCIDENCE FACTOR

N/A

Algorithm

CALCULATION OF ENERGY SAVINGS

ELECTRIC ENERGY SAVINGS

N/A

SUMMER COINCIDENT PEAK DEMAND SAVINGS

N/A

NATURAL GAS SAVINGS

$$\Delta therms = SF * MBH_In * EFLH / 100$$

[433] PA Consulting, Focus on Energy Evaluation, Business Programs: Measure Life Study, August 25, 2009.

Where:

SF = (T_existing – T_eff) / 40°F * TRE

= see default Savings Factor table below

Where:

T_existing = Existing Full Fire Boiler Flue Gas Temperature as it exits the Stack

= 425F[434] (water, 81.9% eff) or custom

= 480F[3] (steam, 80.7% eff) or custom

T_eff = Efficient Full Fire Boiler Flue Gas Temperature as it exits the Stack

= 338°F (conventional economizer – Water Boiler)[435] or custom

= 365°F (conventional economizer – Steam Boiler)[436] or custom

= 280°F (condensing economizer – Water Boiler)[437] or custom

= 308°F (condensing economizer – Steam Boiler)[438] or custom

TRE = % efficiency increase for 40°F of stack temperature reduction

= 1%[439] or custom

Based on defaults provided above:

[434] Cleaver Brooks. March 2012, Boiler Efficiency Guide, Pg. 7, Figure 1.

[435] The minimum stack temperature for a non-condensing economizer is 250°F from Department of Energy (DOE). January 2012, Steam Tip Sheet #26A, Consider Installing a Condensing Economizer. Advanced Manufacturing Office. Washington, DC: U.S. Department of Energy. The average temperature drop is assumed to be ½ way between the existing and efficient temperature minimum, (425°F + 250°F) / 2 = 338°F.

[436] The minimum stack temperature for a non-condensing economizer is 250°F from Department of Energy (DOE). January 2012, Steam Tip Sheet #26A, Consider Installing a Condensing Economizer. Advanced Manufacturing Office. Washington, DC: U.S. Department of Energy. The average temperature drop is assumed to be ½ way between the existing and efficient temperature minimum, (480°F + 250°F) / 2 = 365°F.

[437] The minimum stack temperature for a condensing economizer is 250°F from Department of Energy (DOE). January 2012, Steam Tip Sheet #26A, Consider Installing a Condensing Economizer. Advanced Manufacturing Office. Washington, DC: U.S. Department of Energy. The average temperature drop is assumed to be ½ way between the existing and efficient temperature minimum, (425°F + 135°F) / 2 = 280°F.

[438] The minimum stack temperature for a condensing economizer is 250°F from Department of Energy (DOE). January 2012, Steam Tip Sheet #26A, Consider Installing a Condensing Economizer. Advanced Manufacturing Office. Washington, DC: U.S. Department of Energy. The average temperature drop is assumed to be ½ way between the existing and efficient temperature minimum, (480°F + 135°F) / 2 = 308°F.

[439] United States EPA, Climate Wise: Wise Rules for Industrial Efficiency, July 1998. The Wise Rules indicate savings range of 1-2% per 40°F reduction, so utilizing 1% is a conservative approach.

Boiler Type	SF[440]	
	Conventional Economizer	Condensing Economizer
Hot Water Boiler	2.19% average SF or custom	3.63% average SF or custom
Steam Boiler	2.88% average SF or custom	4.31% average SF or custom

MBH_In = Rated boiler input capacity, in MBH

= Actual

EFLH = Equivalent Full Load Hours for heating are provided in Section 4.4 HVAC End Use

WATER IMPACT DESCRIPTIONS AND CALCULATION

N/A

DEEMED O&M COST ADJUSTMENT CALCULATION

N/A

MEASURE CODE: CI-HVC-BECO-V01-150601

[440] These average values should be utilized in absence of actual temperature data. An economizer with a zero temperature change between the existing and the efficient temperatures would not be installed, so these average values are conservative.

4.4.29 Stack Economizer for Boilers Serving Process Loads

MEASURE DESCRIPTION

Stack economizers are designed to recover heat from hot boiler flue gasses. Recovered heat is used to preheat boiler feed water. This measure describes the retrofit of process boilers with stack economizers. Process boilers are defined as those used for industrial, manufacturing, or other non-HVAC applications. There is another, similar measure for boilers that serve HVAC loads.

This measure was developed to be applicable to the following program types: NC, TOS, RF.

If applied to other program types, the measure savings should be verified.

DEFINITION OF EFFICIENT EQUIPMENT

To qualify the economizer must be installed on a boiler exhaust stack. Heat captured by the economizer is to be used to pre-heat boiler feed water.

DEFINITION OF BASELINE EQUIPMENT

The baseline boiler does not have an economizer installed.

DEEMED LIFETIME OF EFFICIENT EQUIPMENT

The measure life for the boiler stack economizer is 15 years.[441]

DEEMED MEASURE COST

The incremental and full measure cost for this measure is custom.

DEEMED O&M COST ADJUSTMENTS

The O&M cost for this measure is custom.

LOADSHAPE

N/A

COINCIDENCE FACTOR

N/A

[441] PA Consulting, Focus on Energy Evaluation, Business Programs: Measure Life Study, August 25, 2009.

Algorithm

CALCULATION OF ENERGY SAVINGS

ELECTRIC ENERGY SAVINGS

N/A

SUMMER COINCIDENT PEAK DEMAND SAVINGS

N/A

NATURAL GAS SAVINGS

Δtherms = SF * MBH_In * 8766 * UF / 100

Where:

SF = (T_existing – T_eff)/40°F * TRE

= see default Savings Factor table below

T_existing = Existing Full Fire Boiler Flue Gas Temperature as it exits the Stack

= 425F[442] (water, 81.9% eff per IL TRM) or custom

= 480F[3] (steam, 80.7% eff per IL TRM) or custom

T_eff = Efficient Full Fire Boiler Flue Gas Temperature as it exits the Stack

= 338°F (conventional economizer – Water Boiler)[443] or custom

= 365°F (conventional economizer – Steam Boiler)[444] or custom

= 280°F (condensing economizer – Water Boiler)[445] or custom

= 308°F (condensing economizer – Water Boiler)[446] or custom

[442] Cleaver Brooks. March 2012, Boiler Efficiency Guide, Pg. 7, Figure 1.

[443] The minimum stack temperature for a non-condensing economizer is 250°F from Department of Energy (DOE). January 2012, Steam Tip Sheet #26A, Consider Installing a Condensing Economizer. Advanced Manufacturing Office. Washington, DC: U.S. Department of Energy. The average temperature drop is assumed to be ½ way between the existing and efficient temperature minimum, (425°F + 250°F) / 2 = 338°F.

[444] The minimum stack temperature for a non-condensing economizer is 250°F from Department of Energy (DOE). January 2012, Steam Tip Sheet #26A, Consider Installing a Condensing Economizer. Advanced Manufacturing Office. Washington, DC: U.S. Department of Energy. The average temperature drop is assumed to be ½ way between the existing and efficient temperature minimum, (480°F + 250°F) / 2 = 365°F.

[445] The minimum stack temperature for a condensing economizer is 250°F from Department of Energy (DOE). January 2012, Steam Tip Sheet #26A, Consider Installing a Condensing Economizer. Advanced Manufacturing Office. Washington, DC: U.S. Department of Energy. The average temperature drop is assumed to be ½ way between the existing and efficient temperature minimum, (425°F + 135°F) / 2 = 280°F.

[446] The minimum stack temperature for a condensing economizer is 250°F from Department of Energy (DOE). January 2012,

TRE = % efficiency increase for 40°F of stack temperature reduction

= 1%[447] or custom

Based on defaults provided above:

Boiler Type	SF[448]	
	Conventional Economizer	Condensing Economizer
Hot Water Boiler	2.19% average SF or custom	3.63% average SF or custom
Steam Boiler	2.88% average SF or custom	4.31% average SF or custom

MBH_In = Rated boiler input capacity, in MBH

= Actual

8766 = Hours a year

UF = Utilization Factor

= 41.9%[449] or custom

WATER IMPACT DESCRIPTIONS AND CALCULATION

N/A

DEEMED O&M COST ADJUSTMENT CALCULATION

N/A

MEASURE CODE: CI-HVC-PECO-V01-150601

Steam Tip Sheet #26A, Consider Installing a Condensing Economizer. Advanced Manufacturing Office. Washington, DC: U.S. Department of Energy. The average temperature drop is assumed to be ½ way between the existing and efficient temperature minimum, (480°F + 135°F) / 2 = 308°F.

[447] United States EPA, Climate Wise: Wise Rules for Industrial Efficiency, July 1998. The Wise Rules indicate savings range of 1-2% per 40°F reduction, so utilizing 1% is a conservative approach.

[448] These average values should be utilized in absence of actual temperature data. An economizer with a zero temperature change between the existing and the efficient temperatures would not be installed, so these average values are conservative.

[449] Work Paper – Tune up for Boilers serving Space Heating and Process Load by Resource Solutions Group, January 2012

4.4.30 Notched V Belts for HVAC Systems

MEASURE DESCRIPTION

This measure is for replacement of smooth v-belts in non-residential package and split HVAC systems with notched v-belts. Typically there is a v-belt between the motor and the supply air fan and/or return air fan in larger package and split HVAC systems (RTU).

In general there are two styles of grooved v-belts, notched and synchronous. The DOE defines each as follows;

Notched V-Belts - A notched belt has grooves or notches that run perpendicular to the belt's length, which reduces the bending resistance of the belt. Notched belts can use the same pulleys as cross-section standard V-belts. They run cooler, last longer, and are about 2% more efficient than standard V-belts.

Synchronous Belts - Synchronous belts (also called cogged, timing, positive-drive, or high-torque drive belts) are toothed and require the installation of mating grooved sprockets. These belts operate with a consistent efficiency of 98% and maintain their efficiency over a wide load range.

Smooth v-belts are usually referred to in five basic groups:

- "L" belts are low end belts that are for small, fractional horsepower motors and these are not used in RTUs.
- "A" and "B" belts are the two types typically used in RTUs. The "A" belt is a ½ inch width by 5/16 inch thickness and the "B" belt is larger, 21/32 inch wide and 12/32 inch thick so it can carry more power. V-belts come in a wide variety of lengths where 20 to 100 inches is typical.
- "C" and "D" belts are primarily for industrial applications with high power transmission requirements.
- V-belts are provided by various vendors. The notched version of these belts typically have an "X" added to the designation. For this HVAC fans notched v-belt Replacement measure, only the "A" and "B" v-belts are considered. A typical "A" v-belt is replaced by a notched "AX" v-belt and a "B" is replaced by a "BX." In general, smooth v-belts have an efficiency of 90% to 98% while notched v-belts have an efficiency of 95% to 98%. Because notched v-belts are more flexible they work with smaller diameter pulleys and they have less resistance to bending. Lower bending resistance increases the power transmission efficiency, lowers the waste heat, and allows the belt to last longer than a smooth belt.

Three research papers[450] [451] [452] show that the notched v-belt efficiency is 2% to 5% better than a typical smooth v-belt. A fourth paper by USDOE's Energy Efficiency and Renewable Energy[453] group reviewed most of the earlier literature and recommended using a conservative 2% efficiency improvement for energy savings for calculations.

For this measure it is assumed that upgrading a standard smooth v-belt with a new notched v-belt will result in a fan energy reduction of 2%.

---

[450] "Gates Corporation Announces New EPDM Molded Notch V-Belts," The Gates Rubber Co., June 2010 (Assumed 3% efficiency improvement) https://ww2.gates.com/news/index.cfm?id=11296&show=newsitem&location_id=753&view=Gates

[451] "Synchronous Belt Drives Offer Low Cost Energy Savings," Baldor., February 2009. (attached in Reference Documents)

[452] "Energy Savings from Synchronous Belts," The Gates Rubber Co., February 2014. (Assumed 5% efficiency improvement) http://www.gates.com/~/media/Files/Gates/Industrial/Power%20Transmission/White%20Papers/Energy%20Savings%20from%20Synchronous%20Belt%20Drives.pdf

[453] "Motor System Tip Sheet #5, Replace V-Belts with Cogged or Synchronous Belt Drives," USDOE-EERE, September 2005. (Assumed 2% efficiency improvement) http://www1.eere.energy.gov/industry/bestpractices/pdfs/replace_vbelts_motor_systemts5.pdf

DEFINITION OF EFFICIENT EQUIPMENT

The Efficient Equipment is HVAC RTUs that have notched v-belts installed on the supply and/or return air fans.

DEFINITION OF BASELINE EQUIPMENT

The Baseline Equipment is HVAC RTUs that have smooth v-belts installed on the supply and/or return air fans (i.e. RTU does not already have a notched v-belt installed).

DEEMED LIFETIME OF EFFICIENT EQUIPMENT

A v-belt has a life based on fan run hours which varies by building type based primarily on occupancy schedule because the fans are required by code to operate continuously during occupied hours. The supply and return fans will also run a few hours during unoccupied hours for heating and cooling as needed. For the notched v-belt EUL calculation, the default hours[454] in the following table are used for a variety of building types and HVAC applications.

EUL = Belt Life / Occupancy Hours per year

Where:

Belt Life = 24,000 hours[455]

Occupancy Hours per year = values from Table below

The notched v-belt measure EUL is summarized by building type in the following table.

Notched v-belt Effective Useful Life (EUL)

Building Type	Pumps & Fans (annual Hours of operation)	EUL (Years)
College/University	4216	5.7
Grocery	5840	4.1
Heavy Industry	3585	6.7
Hotel/Motel	6872	3.5
Light Industry	2465	9.7
Medical	6871	3.5
Office	2301	10.4
Restaurant	4654	5.2

[454] ComEd Trm June 1, 2010 page 139. The Office hours is based upon occupancy from the eQuest model developed for EFLH, since it was agreed the ComEd value was too low.
[455] "DEER2014-EUL-table-update_2014-02-05.xlsx," Database for Energy Efficiency Resources (DEER), Deer 2014. www.deerresources.com (attached in Reference Documents)

Building Type	Pumps & Fans (annual Hours of operation)	EUL (Years)
Retail/Service	3438	7.0
School(K-12)	2203	10.9
Warehouse	3222	7.4
Average=Miscellaneous	4103	5.8

DEEMED MEASURE COST

A review of the Grainger online[456] pricing for "A," "B," "AX," and "BX" v-belts showed the incremental cost to upgrade to notched v-belts would result in a 28% price increase. The notched v-belt incremental cost is summarized in the table below:

Notched V-belt Incremental Cost Summary

Smooth V-Belt Industry Number	Outside Length (Inches)	Dayton Smooth V-Belt*	Notched V-belt Industry Number	Dayton Notched v-belt*	Price Increase	% Increase
A30 (Item # 1A095)	32	$12.70	AX29 (Item # 3GWU4)	$17.65	$4.95	28%
B29 (Item # 6L208)	32	$16.75	BX29 (Item # 5TXL4)	$23.23	$6.48	28%
* Pricing based on Dayton Belts as found on Grainger Website 10/30/14						

DEEMED O&M COST ADJUSTMENTS

N/A

LOADSHAPE

Loadshape C05 - Commercial Electric Heating and Cooling

COINCIDENCE FACTOR

N/A

[456] Grainger catalog on-line web-site for Dayton v-belt pricing
http://www.grainger.com/Grainger/ecatalog/N-1z0r596/Ntt-v-belts

Algorithm

CALCULATION OF ENERGY SAVINGS

Electric Energy Savings

$$\Delta kWh = kW_{connected} * Hours * ESF$$

Where:

$kW_{Connected}$ =kW of equipment is calculated using motor efficiency[457].

= (HP * 0.746 kW/HP* Load Factor)/Motor Efficiency

Load Factor =Motors are assumed to have a load factor of 80% for calculating KW if actual values cannot be determined[458]. Custom load factor may be applied if known.

Motor Efficiency = Actual motor efficiency shall be used to calculate KW. If not known a value from the motor efficiency refrence tables below should be used[459]

Baseline Motor Efficiencies (EPACT)						
Size HP	Open Drip Proof (ODP)			Totally Enclosed Fan-Cooled (TEFC)		
	# of Poles					
	6	*4*	*2*	*6*	*4*	*2*
	Speed (RPM)					
	1200	*1800*	*3600*	*1200*	*1800*	*3600*
1/8	-	44.00%	-	-	-	-
1/6	57.50%	62.00%	-	-	-	-
1/4	68.00%	68.00%	-	68.00%	64.00%	-
1/3	70.00%	70.00%	72.00%	70.00%	68.00%	72.00%
1/2	78.50%	80.00%	68.00%	72.00%	74.00%	68.00%
3/4	77.00%	78.50%	74.00%	77.00%	75.50%	74.00%
1	80.00%	82.50%	75.50%	80.00%	82.50%	75.50%
1.5	84.00%	84.00%	82.50%	85.50%	84.00%	82.50%
2	85.50%	84.00%	84.00%	86.50%	84.00%	84.00%

[457] Note that kWConnected may be determined using various methodologies. The examples provided use rated HP and assumed load factor. Other methodologies include rated voltage and full load current with assumed load factor, or actual measured voltage and current.
[458] Com Ed TRM June 1, 2010
[459] Efficiency values for motors less than one HP taken from Baldor Electric Catalog 501: http://www.baldor.com/pdf/501_Catalog/CA501.pdf

Baseline Motor Efficiencies (EPACT)						
3	86.50%	86.50%	84.00%	87.50%	87.50%	85.50%
5	87.50%	87.50%	85.50%	87.50%	87.50%	87.50%
7.5	88.50%	88.50%	87.50%	89.50%	89.50%	88.50%
10	90.20%	89.50%	88.50%	89.50%	89.50%	89.50%
15	90.20%	91.00%	89.50%	90.20%	91.00%	90.20%
20	91.00%	91.00%	90.20%	90.20%	91.00%	90.20%
25	91.70%	91.70%	91.00%	91.70%	92.40%	91.00%

Efficient Motor Efficiencies (NEMA Premium)						
Size HP	Open Drip Proof (ODP)			Totally Enclosed Fan-Cooled (TEFC)		
	# of Poles			# of Poles		
	2	4	6	2	4	6
	Speed (RPM)			Speed (RPM)		
	1200	1800	3600	1200	1800	3600
0.125 *	-	44.00%	-	-	-	-
1/6	57.50%	62.00%	-	-	-	-
1/4	68.00%	68.00%	-	68.00%	64.00%	-
1/3	70.00%	70.00%	72.00%	70.00%	68.00%	72.00%
1/2	78.50%	80.00%	68.00%	72.00%	74.00%	68.00%
3/4	77.00%	78.50%	74.00%	77.00%	75.50%	74.00%
1	82.50%	85.50%	77.00%	82.50%	85.50%	77.00%
1.5	86.50%	86.50%	84.00%	87.50%	86.50%	84.00%
2	87.50%	86.50%	85.50%	88.50%	86.50%	85.50%
3	88.50%	89.50%	85.50%	89.50%	89.50%	86.50%
5	89.50%	89.50%	86.50%	89.50%	89.50%	88.50%
7.5	90.20%	91.00%	88.50%	91.00%	91.70%	89.50%
10	91.70%	91.70%	89.50%	91.00%	91.70%	90.20%
15	91.70%	93.00%	90.20%	91.70%	92.40%	91.00%
20	92.40%	93.00%	91.00%	91.70%	93.00%	91.00%
25	93.00%	93.60%	91.70%	93.00%	93.60%	91.70%

Hours = When available, actual hours should be used. If actual hours are not available default hours[460] are provided in table below for HVAC fan operation which varies by building type:

Building Type	Pumps & Fans (annual Hours of operation)
College/University	4216
Grocery	5840
Heavy Industry	3585
Hotel/Motel	6872
Light Industry	2465
Medical	6871
Office	2301
Restaurant	4654
Retail/Service	3438
School(K-12)	2203
Warehouse	3222
Average=Miscellaneous	4103

ESF = Energy Savings Factor, the ESF for notched v-belt Installation is assumed to be 2%

[460] ComEd Trm June 1, 2010 page 139. The Office hours is based upon occupancy from the eQuest model developed for EFLH, since it was agreed the ComEd value was too low.

EXAMPLE

For example, an office building RTU with a 5 HP NEMA premium efficiency motor using the default hours of operation, motor load and 89.5% motor efficiency;

$\Delta kWh = kW_{connected} * Hours * ESF$

= ((HP * 0.746 kW/HP* Load Factor)/Motor Efficiency) * Hours * ESF

= ((5 HP * 0.746 kW/HP* 80%) / 89.5%) * 1766 Hours * 2%

= 117.8 kWh Savings

SUMMER COINCIDENT PEAK DEMAND SAVINGS

$\Delta kW = kW_{connected} * ESF$

Where:

$kW_{Connected}$ = kW of equipment is calculated using motor efficiency.

= (HP *0 .746 kW/HP* Load Factor)/Motor Efficiency

Variables as provided above

EXAMPLE

For example, an office building RTU with a 5 HP NEMA premium efficiency motor using the default motor load and 89.5% motor efficiency;

$\Delta kW = kW_{connected} * ESF$

= ((HP * 0.746 kW/HP* Load Factor)/Motor Efficiency) * ESF

= ((5 HP * 0.746 kW/HP* 80%) / 89.5%) * 2%

= 0.0667 kW Savings

NATURAL GAS SAVINGS

N/A

WATER IMPACT DESCRIPTIONS AND CALCULATION

N/A

DEEMED O&M COST ADJUSTMENT CALCULATION

N/A

MEASURE CODE: CI-MSC-NVBE-V01-150601

4.4.31 Small Business Furnace Tune-Up

DESCRIPTION

This measure is for a natural gas Small Business furnace that provides space heating. The tune-up will improve furnace performance by inspecting, cleaning and adjusting the furnace and appurtenances for correct and efficient operation. Additional savings maybe realized through a complete system tune-up.

This measure was developed to be applicable to the following program types: Small business.

If applied to other program types, the measure savings should be verified.

DEFINITION OF EFFICIENT EQUIPMENT

To qualify for this measure an approved technician must complete the tune-up requirements[461] listed below:

- Measure combustion efficiency using an electronic flue gas analyzer
- Check and clean blower assembly and components per manufacturer's recommendations
- Where applicable Lubricate motor and inspect and replace fan belt if required
- Inspect for gas leaks
- Clean burner per manufacturer's recommendations and adjust as needed
- Check ignition system and safety systems and clean and adjust as needed
- Check and clean heat exchanger per manufacturer's recommendations
- Inspect exhaust/flue for proper attachment and operation
- Inspect control box, wiring and controls for proper connections and performance
- Check air filter and clean or replace per manufacturer's
- Inspect duct work connected to furnace for leaks or blockages
- Measure temperature rise and adjust flow as needed
- Check for correct line and load volts/amps
- Check thermostat operation is per manufacturer's recommendations (if adjustments made, refer to 'Small Commercial Programmable Thermostat Adjustment' measure for savings estimate)
- Perform Carbon Monoxide test and adjust heating system until results are within standard industry acceptable limits

DEFINITION OF BASELINE EQUIPMENT

The baseline is furnace assumed not to have had a tune-up in the past 2 years.

DEEMED LIFETIME OF EFFICIENT EQUIPMENT

The measure life for the tune up is 2 years.[462]

DEEMED MEASURE COST

The incremental cost for this measure should be the actual cost of tune up.

---

[461] American Standard Maintenance for Indoor Units: http://www.americanstandardair.com/owner-support/maintenance.html
[462] Act on Energy Commercial Technical Reference Manual No. 2010-4, 9.2.3 Gas Forced-Air Furnace Tune-up.

DEEMED O&M COST ADJUSTMENTS

There are no expected O&M savings associated with this measure.

LOADSHAPE

Loadshape C04 - Commercial Electric Heating

COINCIDENCE FACTOR

N/A

Algorithms

CALCULATION OF ENERGY SAVINGS

ELECTRIC ENERGY SAVINGS

$\Delta kWh = \Delta Therms * F_e * 29.3$

Where:

$\Delta Therms$ = as calculated below

F_e = Furnace Fan energy consumption as a percentage of annual fuel consumption

= 3.14%[463]

29.3 = kWh per therm

SUMMER COINCIDENT PEAK DEMAND SAVINGS

N/A

NATURAL GAS SAVINGS

$\Delta therms = (Capacity * EFLH * (((Effbefore + Ei)/ Effbefore) – 1)) / 100,000$

Where:

Capacity = Furnace gas input size (Btu/hr)

[463] F_e is not one of the AHRI certified ratings provided for residential furnaces, but can be reasonably estimated from a calculation based on the certified values for fuel energy (Ef in MMBtu/yr) and Eae (kWh/yr). An average of a 300 record sample (non-random) out of 1495 was 3.14%. This is, appropriately, ~50% greater than the Energy Star version 3 criteria for 2% F_e. See "Programmable Thermostats Furnace Fan Analysis.xlsx" for reference.

= Actual

EFLH = Equivalent Full Load Hours for heating are provided in section 4.4 HVAC End Use

Effbefore = Efficiency of the furnace before the tune-up

= Actual

EI = Efficiency Improvement of the furnace tune-up measure

= Actual

100,000 = Converts Btu to therms

EXAMPLE

A 200 kBtu furnace in a Rockford low rise office records an efficiency prior to tune up of 82% AFUE and a 1.8% improvement in efficiency are tune up:

$$\Delta therms = (200{,}000 * 1428 * (((0.82 + 0.018)/ 0.82) - 1)) /100{,}000$$

$$= 62.3 \text{ therms}$$

WATER IMPACT DESCRIPTIONS AND CALCULATION

N/A

DEEMED O&M COST ADJUSTMENT CALCULATION

N/A

O&M COST ADJUSTMENT CALCULATION

N/A

MEASURE Code: CI-HVC-FTUN-V01-150601